

High-level disinfection of sink drains using SoChlor DST



1 Wear disposable gloves and apron



2 Fill SoChlor 2L diluter with cold tap water. Then pour down the drain to pre-flush any residual chemicals



3 Refill the 2 litre SoChlor diluter halfway, with 1 litre of cold tap water. Add 10 tablets and wait until dissolved



4 Slowly pour the solution from the diluter directly into the drain from a height no greater than 10cm



5 Wait 5 minutes



6 Run cold water at a slow rate from the tap for 1 minute

GV
Labs



**From GV Health Labs
& Technical Team**

Contact us to request
the full process guide

